2050A Emulations	Hitachi	Hitachi	Hitachi	Ikegami	Ikegami	Ikegami	Ikegami	Ikegami	Ikegami	JVC	JVC	Panasonic	Panasonic	Panasonic	Panasonic	Panasonic	Sony	Sony	Sony	Sony	Sony
	RC-Z1	RC-Z2	RC-Z3	RM-10	RM-11	RCU-240	RCU-241	RC-390	RC-400	RM-LP25	RM-LP35	AJ-EC1	AJ-EC2	AJ-EC3	WV-CB700AE	10G	RM-P9	RM-M7G	DXC-##	RMB-150	RMB-750
Default I/O	RS422	RS422	RS422	RS422	RS422	RS422	RS422	RS422	RS422	RS422	RS422	RS422	RS422	RS422	Pan 1w	RS422	RS232	Sony 1w	RS422	RS422	RS422
				under	under	under	under	under	under											under	under
FUNCTION				dev	dev	dev	dev	dev	dev											dev	dev
ON/OFF	●	●	●	●	●			●	●	●	●	●	●	●	●	●	●	●	●	●	●
CALL										●1	●1										
VTR															●	●	●	●			
BARS	●	●	●	●	●			●	●	●	●	●	●	●	●	●	●	●	●		
ENGr															●	●	●		●		
MENU - Camera												●	●	●	●	●	●				
SHUTTER - Speeds										●	●	●	●	●	●	●	●		●		
- Variable										●	●					●			●		
- Norm										●	●	+	+	+		●	+	+	●		
GAIN - Auto										●	●										
-Levels	●	●	●							●	●	+	+	+	●	●	+	+	●		
BALANCE - Color	●	●	●	●	●			●	●	●	●	●	●	●	●	●	●	●	●		
- Red Gain	●	●	●	●	●			●	●	●	●	●	●	●	●	●	●	●	●		
- Blue Gain	●	●	●	●	●			●	●	●	●	●	●	●	●	●	●	●	●		
- Red Ped	●	●	●	●	●			●	●	●	●	●	●	●	●	●	●	●	●		
- Blue Ped	●	●	●	●	●			●	●	●	●	●	●	●	●	●	●	●	●		
- Preset	●	●	●	●	●			●	●	●	●	●	●	●		●	●	●	●		
- Auto1	●	●	●	●	●			●	●	●	●	●	●	●	●	●	●	●	●		
- Auto2	●	●	●	●	●			●	●	●	●	●	●	●	●	●	●	●	ATW		
- ABB	●	●	●	●	●			●	●	●	●	●	●	●	●	●	●	●	●		
- AWB	●	●	●	●	●			●	●	●	●	●	●	●	●	●	●	●	●		
SCENE FILE 0 - 4	+	+	+	+	+			+	+	●	+	+	+	+	●+	●	+	+	+		
KNEE - Auto										●	●					●	●	●	●		
- Preset										●	●					●	●	●	●		
- Variable										●	●					●	●	●	●		
BLACK Stretch										●	●										
IRIS - Auto	●	●	●							●	●	●	●	●	●	●	●	●	●		
- Variable	●	●	●							●	●	●	●	●	●	●	●	●	●	●	●
- Joystick	+	+	+	+	+			+	+	●	●	+	+	+	+	+	+	+	+	+	+
GAMMA - Variable										●	●					●	●	●	●		
DETAIL - Variable	●	●	●							●	●				●	●	●	●	●		
PEDESTAL - Joystick	+	+	+	+	+			+	+	●	●	+	+	+	+	+	+	+	+	+	+
PREVIEW - Joystick	+	+	+	+	+			+	+	●	●	+	+	+	+	+	+	+	+	+	+
MODE - 0 - Iris ctrl latch	●	●	●	●	●			●	●	●	●	●	●	●	●	●	●	●	●		
-1																					
-2																					
-3																					
-4																					
Rotary Encoder ADJUST	●	●	●	●	●			●	●	●	●	●	●	●	●	●	●	●	●		
Rotary Encoder Switch	●	●	●	●	●			●	●	●	●	●	●	●	●	●	●	●	●		
Tally - RCP	●	●	●	●	●			●	●	●	●	●	●	●		●	●	●	●		
- camera										●1	●1										
Network capable																				-	-

		Hitachi	Hitachi	Hitachi	Ikegami	Ikegami	Ikegami	Ikegami	Ikegami	Ikegami	JVC	JVC	Panasonic	Panasonic	Panasonic	Panasonic	Panasonic	Sony	Sony	Sony	Sony	Sony
		RC-Z1	RC-Z2	RC-Z3	RM-10	RM-11	RCU-240	RCU-241	RC-390	RC-400	RM-LP25	RM-LP35	AJ-EC1	AJ-EC2	AJ-EC3	WV-CB700AE	10G	RM-P9	RM-M7G	DXC-##	RMB-150	RMB-750
	Cameras Tested	Z-oneD	Z-oneD	Z-oneD	HC-390	HC-390	HC-390	HC-390	HC-390	HC-400	GY-HD251	GY-HD251	AJ-D600	AJ-D600	AJ-D600	AW-E300	HDX900	DNW-90P	DXC-D30	DXC-D35	PDW-510	PDW-510
			V-21W	V-21W	HC-400	HC-400	HC-400	HC-400	HC-400	HC-500	KY-D29W	KY-D29W	AJ-D800	AJ-D800	AJ-D800	AW-E600	HPX-500	DXC-D50	DXC-D35	DXC-D50	F-900	F-900
										HDL-51	FY-560	FY-560	AJ-D400	AJ-D400	AJ-D400	WV-F500	HPX-2100	DSR-300	DSR-500		HDW-750	HDW-750
										HL-45						WV-F700		DSR-500	DSR-570		HDW-790	HDW-790
	* Not all OCU settings available for camera control																					
	+ Additional feature																					
	- no feature																					
	●1 Cam to Studio tally mode																					
	2009-04-15																					