dTS DIGITAL TELEVISION SYSTEMS LTD

www.triax.tv

## 1500 Triax/coax System Camera/camcorder List

April 2009

| Hitachi | |
|---|---|
| Camera | ocp/rcp |
| | |
| V21 | RC-Z1 |
| V21-W | RC-Z11 |
| Z1-A | RC-2 |
| Z1-B | RC-21 |
| Z1-C | RC-2A |
| Z1-D | RC-Z21A |
| Z-3500 | |
| Z-3500/W | |
| V-35 | |
| V-35W | |
| Z-2500 | |
| | |
| | |
| | |
| Camcorder | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Ikegami | |
|---|---|
| Camera | ocp/rcp |
| | |
| HC-210 | MCP-388 |
| HC-390 | OCP-40 |
| HC-400 | OCP-45 |
| HC-400W | OCP-388 |
| HC-D57 | RCU-240 |
| HC-D57W | RCU-390 |
| HL-45W | RCU-400 |
| HL-55 | RM-10 |
| HL-59W | RM-11 |
| HL-60W | RM-45 |
| HL-65W | RCP-50 |
| HK-399PW | |
| HK-399W | |
| | |
| Camcorder | |
| HL-DV7W | |
| HL-V73W | |
| HL-V75W | |
| HL-V77W | |
| HL-V79W | |
| DNS-33W | |
| HDN-X10 | |
| HDS-V10 | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| JVC | |
|---|---|
| Camera | ocp/rcp |
| | |
| KY-D29 | RM-LP25U |
| KY-D29W | RM-LP35U |
| KY-F560E | RM-LP55U |
| | RM-LP57U |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| Camcorder | |
| GY-HM700E | |
| GY-HD200E | |
| GY-HD250 | |
| GY-HD251 | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Panasonic | |
|---|---|
| Camera | ocp/rcp |
| | |
| WV-F565E | AQ-EC1 |
| AW-E300 | AQ-EC2 |
| AW-E600 | AQ-EC3 |
| AW-E800 | WV-CB700A |
| | AJ-EC3E |
| | RC-10 |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| Camcorder | |
| AJ-D610 | |
| AJ-D700E | |
| AJ-D800E | |
| AJ-D900WE | |
| AJ-D910WE | |
| AJ-HDC27HE | |
| AJ-HDX900 | |
| AJ-SDC905 | |
| AJ-SDC615 | |
| AJ-HPX3700 | |
| AJ-HPX2700 | |
| AJ-HPX3000 | |
| AJ-HPX2100 | |
| AG-HPX500 | |
| AG-HPX301 | |

| Sony | |
|---|---|
| Camera | ocp/rcp |
| | |
| BVW-400P | RM-M7G |
| DXC-D30P | RM-P9 |
| DXC-D35P | |
| DXC-D50P | |
| DXC-537P | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| Camcorder | |
| DSR-400P | PDW-F335 |
| DSR-450WSP | PDW-F355 |
| DSR-500DV | PDW510P |
| DSR-570 | PDW530P |
| DVW-400AP | PDW-700 |
| DVW-700P | PMW-EX3 |
| DVW-700WSP | |
| DVW-790WSP | |
| DVW-970P | |
| HDW-650P | |
| HDW-730S | |
| HDW-750P | |
| HDW-790P | |
| HDW-F900R | |
| MSW-970P | |

| Others | |
|---|---|
| Camera | ocp/rcp |
| | |
| LDK400 | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| Camcorder | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

**Note: If your camera is not on the list, please contact Customer support as we are constantly adding cameras/camcorders at customers request**